



8TH INTERNATIONAL CONFERENCE
ON SUSTAINABLE SOLID WASTE MANAGEMENT
23 - 26 JUNE 2021, THESSALONIKI, GREECE



Evaluation of the polymeric membranes' performance in terms of laboratory-scale CO₂ removal/separation from biogas

*Chrysovalantou Koutsiantzi^{1, *}, Eustathios Kikkinides¹, Manassis Mitrakas¹, Anastasios Zouboulis², Ioannis Kellartzis¹, George Stavropoulos¹*

¹ Department of Chemical Engineering, Aristotle University of Thessaloniki, 54124, Thessaloniki, Greece

² Department of Chemistry, Aristotle University of Thessaloniki, 54124, Thessaloniki, Greece

** Corresponding e-mail: vkoutsiantzi@gmail.com*



Introduction (1/3)

- Increasing organic waste disposal → emergent need for their use, aiming to energy recovery and nutrients' recycling
- **Anaerobic Digestion (AD)** → Crude biogas production, consisting of:
 - Methane (50-75%), Carbon Dioxide (50-25%)
 - Minor impurities (Hydrogen Sulfide H_2S , NH_3 , Moisture, Siloxanes)
- Necessity of pre-treatment for the elimination of minor impurities
- **Biogas Upgrade** using polymeric membranes
- **Purpose:** 95% CH_4 Purity



Introduction (2/3)

- Asymmetric Hollow fiber (HF) membranes
 - Hollow fibers: bundled in compact volume
 - Shell: hollow fibers' housing
- Separation principle:
 - Permeability difference of gases
 - Pressure difference between shell and fibers
- **Retentate** Stream: Product gas, rich in Methane
- **Permeate** Stream: Recycling stream, rich in Carbon Dioxide



Introduction (3/3)



Polysulfone HF 2-stage membrane

Polymeric membranes' main benefits when applied for biogas upgrade

- (+) Wide commercial use
- (+) High Perm-selectivity
- (+) Low production cost
- (+) Easy to scale up
- (-) Plasticization, physical aging problems



Purpose


- Investigation of a biogas upgrade system using polymeric membranes
- Evaluation of various polymeric membranes
- Design of a membrane setup for the upgrade of biogas on a laboratory scale
- Simultaneous recycling of captured CO₂



Experimental Setup (1/4)



- **Flowchart of the experimental set-up**



PI: Pressure Indicator

PC: Pressure Controller

MFC: Mass Flow Controller

F: Flowmeter

BPR: Back Pressure Regulator



Experimental Setup (2/4)



Experimental conditions for gas separation tests.

Experimental condition	Mixed gas separation (CH ₄ /CO ₂)
Feed gas composition, (%vol)	55/45, 60/40, 65/45, 70/30
Feed pressure, (bar)	0.7 – 1.5
Permeate pressure, (bar)	0
Feed temperature, (°C)	20





Experimental Part (3/4)

Properties of used membrane	Type: MCH-1512A
Hollow fiber material	Polysulfone
Hollow fiber OD, (mm)	55
Length, L (m)	0.365
Effective area (m²)	1.4

- Countercurrent flow



Experimental Part (4/4)




Gas separation experiments

- ▶ Binary gas mixture of CH_4 and CO_2
- 2-stage membrane module
- Back Pressure Regulator
- Mass flow controllers/Flow meters for each stream
- Gas Analyzer (Rapidox 3100EAM)



Results (1/8)

Figure 1: Gas separation performance for various feed pressure values (0.7 - 1.5 bar) (gas composition: 55% CH₄/45% CO₂)




Increase of CH₄ purity when CH₄ recovery diminishes.
Purity > 95% around 40% recovery.



Results (2/8)

Figure 2: Gas separation performance for various back pressure values (0.7 - 1.5 bar) (gas composition: 60% CH₄/40% CO₂)




Increase of CH₄ purity when CH₄ recovery reduces.
Purity > 95% around 40% recovery.



Results (3/8)

Figure 3: Gas separation performance for various back pressure values (0.7 - 1.5 bar) (gas composition: 65% CH₄/35% CO₂)




Increase of CH₄ purity when CH₄ recovery reduces.
Purity > 95% around 40% recovery.



Results (4/8)

Figure 4: Gas separation for various back pressure values (0.7 - 1.5 bar)
(gas composition: 70% CH₄/30% CO₂)




Increase of CH₄ purity when CH₄ recovery reduces.
Purity > 95% around 40% recovery.



Results (5/8)

Figure 5: Effect of stage cut on CH₄ purity for various feed pressure values (0.7 - 1.5 bar) (gas composition: 55% CH₄/45% CO₂)




Increase of stage cut values leads to higher CH₄ purity.
Purity > 95% when stage cut > 0.74 for feed pressure = 1.1 bar



Results (6/8)

Figure 6: Effect of stage cut on CH₄ purity for various feed pressure values (0.7 - 1.5 bar) (gas composition: 60% CH₄/40% CO₂)




Increase of stage cut values leads to higher CH₄ purity.
Purity > 95% when stage cut > 0.75 for feed pressure = 1 bar



Results (7/8)

Figure 7: Effect of stage cut on CH₄ purity for various feed pressure values (0.7 - 1.5 bar) (gas composition: 65% CH₄/35% CO₂)




Increase of stage cut values leads to higher CH₄ purity.
Purity > 95% when stage cut > 0.7 for feed pressure = 0.9 bar



Results (8/8)

Figure 8: Effect of stage cut on CH₄ purity for various feed pressure values (0.7 - 1.5 bar) (gas composition: 70% CH₄/30% CO₂)



Increase of stage cut values leads to higher CH₄ purity.
Purity > 95% when stage cut > 0.7 for feed pressure = 0.9 bar



Conclusions (1/2)

- ▶ High purity biomethane separation is achieved (>95% CH₄) for feed pressures higher than 1 bar
- ▶ CH₄ recovery: decreases with increasing stage cut, while CH₄ purity increases

Optimum conditions :

40% CH₄ recovery → > 95% CH₄ purity

..recovery ratio can be improved with the add of extra modules or recycle streams



Conclusions (2/2)

- ▶ Stage cut: higher stage cut values → higher CH₄ purities

Optimum conditions

Stage cut between 0.7-0.9 → >95% CH₄ purity

(-) Lower stage cut leads in low CH₄ purity or limited biogas capture.



**8TH INTERNATIONAL CONFERENCE
ON SUSTAINABLE SOLID WASTE MANAGEMENT
23 – 26 JUNE 2021, THESSALONIKI, GREECE**



Thank you for your attention



ΕΡΑΝΕΚ 2014-2020
OPERATIONAL PROGRAMME
COMPETITIVENESS • ENTREPRENEURSHIP • INNOVATION



Partnership Agreement 2014-2020

This research has been co-financed by the European Union and Greek national funds through the Operational Program Competitiveness, Entrepreneurship and Innovation, under the call RESEARCH – CREATE – INNOVATE (project code: T2EDK-01293).